



TYPICAL CONNECTION ON ONE OR MORE POLES

1. PROVIDE BREAK-AWAY TRON FUSE HOLDER AND 10 AMP FUSE. FERRAZ-SHAWMUT FEB-11-11-BA OR APPROVED EQUAL. LOCATE INSIDE POLE @ BEHIND HANDHOLE COVER.
2. INSULATE HOT/NEUTRAL SPLICES AS FOLLOWS:  
COVER WITH 2-LAYERS RUBBER TAPE-FILLING VOIDS.  
APPLY 1-LAYER 1/2 LAPPED PVC TAPE  
APPLY 1-LAYER FRICTION TAPE & COAT WITH AN ELECTRICAL INSULATING COATING (SKOTCHKOTE OR EQUAL)
3. SEE ST-24 FOR ADDITIONAL INFORMATION.

**STREETLIGHT  
CONNECTION DIAGRAM**

REF. & REV.  
MARCH 2005  
AUG. 2008  
OCT. 2009

CITY OF MADERA

**ST-23**